




INSTRUCTION MANUAL

CAT-BACK SINGLE EXHAUST SYSTEM

DODGE VAN 5.9L,1500

LONG WHEEL BASE

PART # 316583



ITEM	PART #	QTY	DESCRIPTION
A	788705-A	1	SUPERFLOW MUFFLER
B	700141	1	3" OVERAXLE TAILPIPE
C	700142	1	3" TURNOUT PIPE
D	5757	1	2-1/2" CLAMP
E	OHD300	1	3" CLAMP
F	40073	1	O.E. REAR MUFFLER HANGER
G	500360	1	3-1/2" STAINLESS TIP

Thank you for purchasing our GIBSON EXHAUST SYSTEM for your vehicle. If you need further assistance, please do not hesitate to call our Technical Department at (800) 528-3044, Monday through Friday, 8:00 am to 5:00 pm.

EXHAUST INSTALLATION

PART #316583

WHEN INSTALLING THIS EXHAUST SYSTEM MAKE SURE TO USE PROPER SAFETY PRECAUTIONS. USE JACK STANDS WHEN UNDER VEHICLE, SET PARKING BRAKE, BLOCK TIRES AND USE SAFETY GLASSES AND GLOVES. DO NOT WORK WITH HOT PIPES!

SUGGESTED TOOLS:

9/16" SOCKET, $\frac{1}{2}$ " SOCKET, $\frac{1}{2}$ " WRENCH, JACK STAND

1. Lay out the GIBSON EXHAUST SYSTEM on the floor so it looks like the drawing (NOTE: Drawing is not exact but for placement of parts only.)
2. Unclamp and remove stock muffler at the front inlet and take stock hangers out of grommets and remove stock exhaust and tailpipe. (You may need to cut tailpipe for easy removal)
3. Install muffler to headpipe, tab will rotate muffler to correct clocking (rear outlet of muffler will be at 4 o'clock) Use # D clamp to connect to converter
4. Install rear muffler hanger # F (Open end of U-bolt will be facing driver side.)
5. Install overaxle # B and connect to muffler using # F hanger. (make sure there is 1" clearance between shock and tailpipe).
6. Install #C turnout pipe and connect welded hanger to grommet. Use #E clamp to connect to overaxle.
7. After everything is in proper location and aligned tighten down all clamps.
8. Slip stainless steel tip on and tighten.

SPECIAL NOTES:

- **MAKE SURE YOU HAVE A 1" CLEARANCE ON ALL PIPES FROM ALL RUBBER BRAKE LINES, SHOCK BOOTS, TIRES, ETC.**
- **TO CLEAN STAINLESS STEEL TIP USE A SCOTT BRITE PAD AND ANY STAINLESS OR ALUMINUM CLEANER.**

LEGAL STATUS:

THE GIBSON "CAT-BACK" SYSTEM IS IN COMPLIANCE WITH VC27156 WHEN INSTALLED BEHIND THE CATALYTIC CONVERTER. NO EXEMPTION NUMBER IS NEEDED.