




PERFORMANCE EXHAUST SYSTEMS

INSTALLATION INSTRUCTIONS CAT BACK SPLIT REAR EXHAUST

DODGE RAM 1500 TRUCK 5.7L HEMI
QUAD CAB & STANDARD CAB SHORT BED 4DR 2/4WD
STANDARD CAB, LONG BED 2DR 2WD
PART # 6549



ITEM	PART #	QUANTITY	DESCRIPTION
A	700808	1	3" HEADPIPE W/HANGER
B	789800	1	SUPERFLOW MUFFLER
C	700812	1	2 1/2" PASSENGER SIDE TAILPIPE
D	700870	1	2 1/2" DRIVER SIDE TAILPIPE
E	700346	2	2 1/2" EXIT PIPE
F	08269	1	10" HANGER
G	5757	5	2 1/2" CLAMP
H	OHD300	2	3" CLAMP
I	4337	1	BAND CLAMP
J	500374	2	3 1/2" STAINLESS TIPS
K	BO-1015	1	BOLT KIT FOR BAND CLAMP
L	ZIP	2	ZIP TIES
M	BO-101	1	BOLT KIT FOR HANGER

Thank you for purchasing our Gibson exhaust system for your vehicle. If you need further assistance, please do not hesitate to call our technical dept at (800) 528-3044 Monday through Friday, 8:00 am to 5:00 pm.

INSTALLATION INSTRUCTIONS # 6549

CAREFULLY READ INSTRUCTIONS BEFORE STARTING INSTALLATION.

When installing this exhaust system make sure to use proper safety precautions. Use jack stands when working under the vehicle, set parking brake, block tires and use safety glasses and gloves. Allow exhaust to cool before attempting installation. Severe injury or burns could occur if safety measures are not taken.

SUGGESTED TOOLS: 1/2", 9/16" 15mm wrenches & sockets, WD-40, hacksaw, jack stands.

.....
: **Disconnect the negative battery cable before removal of OEM exhaust. This will allow the computer to reset and**
: **recognize the new exhaust. Lay out the exhaust on the floor so it looks like the drawing and compare parts with manual.**
:



1. To remove the stock exhaust remove it from in front of the stock muffler. Disengage the welded hangers using WD-40 from the OEM rubber grommets. Do not damage or remove the rubber grommets as you will re-use them to mount your new system. Now, cut off tailpipe and remove exhaust.



4. Install passenger side tailpipe #C into muffler 1 1/2"-2". Use clamp #G to secure tailpipe to muffler. DO NOT TIGHTEN. Insert welded hanger into rubber grommet.



5. Use the hole 19 1/2" from the rear of the frame to attach the 10" hanger #F with bolt kit #M. Use the third hole from the top on the hanger.



2. Install head pipe #A onto your existing stock front pipe and attach with clamp #H. Use a jack stand to support the converter. Insert welded hanger into rubber grommet.



6. Install driver side tailpipe #D 1 1/2"-2" into muffler and use clamp #G to secure to muffler. Attach clamp #G to hold up to the hanger #F. DO NOT TIGHTEN.



3. Install muffler #B onto head pipe #A 1 1/2"-2" with the louvers facing towards the converter. Use a jack stand to support the muffler. Use clamp #H to secure the muffler to the headpipe. Slide band clamp #I onto muffler and insert welded hangers into rubber grommets. Attach with bolt kit #K. DO NOT TIGHTEN. Muffler inlet is looking into the louvers.



7. Install exit pipes #E, use clamps #G to secure to tailpipes. DO NOT TIGHTEN. Roll pipes until you have the angle you desire.



8. Install stainless steel tips. Clamp down. When you have everything in place, firmly tighten all bolts and clamps down securely. Use stainless steel cleaner and a Scotch Brite pad weekly to prevent tip from discoloration. Inspect all fasteners after 25-50 miles of operation and re-tighten as necessary

GIBSON EXHAUST systems are designed on a factory stock vehicle. Any aftermarket products installed could increase the sound levels of this Exhaust. **Make sure there is a 1" clearance from ALL rubber brake lines, shock boots, fuel lines, tires, etc to prevent heat related damage or fire.**